

SERVICE BULLETIN

AUTOMATIC MUSIC, INC.



1500 UNION AVENUE. S. E.. GRAND RAPIDS 2. MICHIGAN • TELEPHONE CHERRY 3-3633

May 1, 1961

BULLETIN NO. 189

Subject: Instructions for using Stereo Cartridge with a
Monaural Amplifier

1. Remove the monaural cartridge and install the stereo cartridge.
2. Unsolder the pin terminals from the tone arm cable and replace with the clip terminals packed with the stereo cartridge. The "R" terminal and the "L" terminal on the cartridge should be connected together and both connected to the red wire in the phono cable. The remaining two terminals should be connected together and connected to the black wire in the phono cable. Thus each of the two wires in the phono cable should have two clip terminals soldered to it. The shield on the stereo cartridge should not be grounded at the terminals just as the shield is not grounded at the terminals on the monaural cartridge.
3. Check stylus force after the stereo cartridge is installed to see that it is between 5 and 7 grams.
4. Check needle height and readjust if necessary.

FIELD SERVICE ENGINEERING

SINCE 1909 DESIGNERS, ENGINEERS AND MANUFACTURERS OF AUTOMATIC MUSICAL INSTRUMENTS FOR BUSINESS AND INDUSTRY

AFFILIATE OF *Automatic*
CANTEN COMPANY OF AMERICA