

/// /// /// **ROCK-OLA** /// /// ///

MODEL 1438

(COMET-120)

**PARTS LIST
AND
PRICE CATALOGUE**

December 3, 1953

ROCK-OLA MANUFACTURING CORPORATION
800 NORTH KEDZIE AVENUE
CHICAGO 51, ILLINOIS

MODEL 1438

<u>PART NO.</u>	<u>DESCRIPTION</u>	<u>PRICE</u>
ST-264	1/4-20 X 1-1/2 SCREW	.05
ST-403	6/32 HEX NUT	.20 DZ.
ST-516	DRIV-LOC PIN	.05
ST-752	6/32 X 1-3/4 R.H.M.S.	.40 DZ.
ST-1543	SCREW	.15 DZ.
ST-2244	SQUARE HEAD SET SCREW	.05
ST-2262	ALLEN SET SCREW	.06
ST-2270	ALLEN SET SCREW	.10
ST-2279	8/32 X 1/2 HOLLOW SET SCREW	.10
ST-3072	#47 LIGHT BULB	.15
ST-3090	3 AMP. SLO-BLO FUSE	.20
ST-3092	10 AMP. FUSE	.15
PH-3177	50 MFD. 50 V. CONDENSER	.85
PH-3190	5U4 TUBE	1.55
PH-3191	6L6 TUBE	2.80
PH-3270	2 PRONG SOCKET	.35
PH-3512	.005 MFD. CONDENSER	.12
PH-3523	3 AMP. FUSE	.15
PH-3722	4 PRONG SOCKET	.15
PH-3732	8 PRONG MINIATURE SOCKET	.20
PH-3740	5 PRONG SOCKET	.15
ST-4306	1/10 AMP. FUSETRON	.30
ST-4314	2 AMP. FUSE	.10
ST-4321	1.6 AMP. FUSE	.30
ST-6017	CASTER	.65
ST-6053	CASTER SOCKET	.15
ST-7375	REAR DOOR LOCK	1.50
ST-7380	FRONT DOOR LOCK	1.45
ST-7381	CASH BOX LOCK	1.25
10901	TENSION SPRING	.05
11555	FUSE HOLDER	.55
11556	FLUORESCENT LIGHT STARTER	.45
11559	3 PRONG SOCKET	.45
11578	POINTER KNOB	.25
11609	MICRO SWITCH	1.85
12053	20 W. FLUORESCENT TUBE	1.00
12219-1	COIN RETURN CUP	2.10
12312	COUNTER	3.60
12546	6 SN 7 TUBE	1.50
12769	SPEAKER TERMINAL STRIP	1.55
12994	TONE SWITCH	.55
13015	47,000 OHM RESISTOR	.15
13034	.1 MFD. 600 V. CONDENSER	.35
13206	.STRAIN RELIEF	.15
13322	680,000 OHM RESISTOR	.10
13362	MASTER LINE SWITCH	.75
14011	COIL - ELECTROMAGNET	.75
14014	ARMATURE - RATCHET DETENT	.15
14017	SPACER - RATCHET DETENT	.03

MODEL 1438

<u>PART NO.</u>	<u>DESCRIPTION</u>	<u>PRICE</u>
14018	SPACER	.03
14022	TORSION SPRING	.15
14027	PAWL - RESET	.06
14028	COMPRESSION SPRING	.05
14029	TENSION SPRING	.05
14030	COIL - RESET	.60
14035-A	25¢ RATCHET AND HUB ASSEMBLY	.75
14036-A	10¢ RATCHET AND HUB ASSEMBLY	.45
14037-A	5¢ RATCHET AND HUB ASSEMBLY	1.25
14039-A	RATCHET ESCAPEMENT ARMATURE ASSEMBLY	.75
14041-A	RESET ARMATURE RIVETING ASSEMBLY	.40
14072	COIN SWITCH	4.75 3.00
14097	47 OHM - 1/2 WATT RESISTOR	.10
14132-A	ACCUMULATOR ASSEMBLY	12.50
14261	TENSION SPRING	.05
14363	3 OHM 3 WATT RESISTOR	.25
14365	.05 MFD. CONDENSER	.15
14415	SWITCH - SELECTION IMPULSE	.50
14416	ACCUMULATOR CAPACITOR	3.00
15159	MOMENTARY PUSH SWITCH	.45
15162	VOLUME CONTROL POTENTIOMETER	1.50
15194	.002 MFD. CONDENSER	.15
15204	25 MFD. CAPACITOR	.65
15239	SLUG REJECTOR	22.50
15246	CAM ARM	.10
15254	CONTROL SWITCH USE 15392-A	
15392-A	CONTROL SWITCH ASSEMBLY	1.75
15637	NEEDLE (45 R.P.M.) (1-99) .70 (200-299) .60 (100-199).65 (300-399) .55	
15655	COIN SWITCH GUARD	1.75
15893	REJECT BUTTON SPRING	.05
16157	SPRING ANCHOR	.10
16220	500 M MFD. MICA CAPACITOR	.15
16222	6,800 OHM RESISTOR	.07
16223	10,000 OHM RESISTOR	.07
16228	100,00 OHM RESISTOR	.07
16250	MAGAZINE	4.75
16252	DRIVE GEAR	8.25
16263	SPACER SHAFT	1.25
16279	GRIPPER MOTOR GEAR	1.10
16293	GENEVA GRIPPER TURN-OVER	.55
16294	GENEVA GRIPPER RELEASE	.90
16297	INNER GRIPPER CASTING	2.10
16299	GRIPPER ARM REVERSING CAM	3.00
16305	MICRO SAFETY CAM - OUTER	.65
16313	SELECTOR INSULATOR - BOTTOM	.10
16315	SELECTOR LEVER	.05
16316	ARMATURE SPRING	.15 OZ.
16329	CLAPPER COIL	.95

MODEL 1438

<u>PART NO.</u>	<u>DESCRIPTION</u>	<u>PRICE</u>
16330	SELECTOR COIL	.40
16339-A	SELECTOR TOP PLATE ASSEMBLY	2.75
16344	SPACER PIN	.25
16347	COIL MOUNTING BRACKET	.25
16348	COIL MOUNTING BRACKET	.08
16349	CONTACT RETAINER	.07
16350	SPACER PIN RETAINER	.05
16351-1	CONTACT BLOCK - ONLY	.75
16381	GRIPPER CONNECTING ROD	.30
16395	TRAY DECAL	.40
16440	MAGAZINE DRIVE PINION	.55
16501	PROGRAM HOLDER (REAR) 1-30	.95
16502	" " " 31-60	.95
16503	" " " 61-90	.95
16504	" " " 91-120	.95
16515-1	KEY PLATE	8.50
16532	COUNTER DECAL	.15
16561	END KEY SWITCH	5.75
16572-A	SELECTOR STRIP CONTACT ASSEMBLY	1.25
16574-A	CLAPPER ASSEMBLY	2.85
16575-A	CLAPPER BRACKET ASSEMBLY	.55
16577-A	CLAPPER ARMATURE RIVETING ASSEMBLY	.80
16613-A	CARRIAGE HOUSING AND TERMINALS (ONLY)	2.00
16645-A	EXTERNAL SHAFT ASSEMBLY	7.50
16654-A	COUNTER SIDE PLATE ASSEMBLY (R.H.)	.50
16655-A	COUNTER SIDE PLATE ASSEMBLY (L.H.)	.50
16657-A	ROLLER MOUNTING PLATE ASSEMBLY	.70
16658-A	COUNTER DISC ASSEMBLY	.25
16671-A	GRIPPER SPIDER ASSEMBLY	3.25
16683-A	GRIPPER REVERSING BRACKET ASSEMBLY	1.25
16610	MINIATURE 4 PRONG SOCKET	.15
16612	RECTIFIER	1.25
16816	12 CONTACT MALE CONNECTOR	.60
16851	12 CONTACT FEMALE SOCKET	.70
16853	21 POSITION JONES SOCKET	1.25
16900	5 PRONG PLUG AND SHELL	.50
16904	PHONOGRAPH CONNECTOR	.20
16912	MECHANISM SERVICE SWITCH	2.10
16913	RECORD LOAD SWITCH	2.00
16922	SELECTOR BUTTON (GREEN)	.10
16924	INPUT CAPACITOR (20 MFD.)	.80
15925	FILTER RESISTOR	.60
15926	FILTER CAPACITOR	1.75
16927	200 OHM RESISTOR	.50
16979-A	GRIP CAM SWITCH AND BRACKET ASSEM.	4.00
17008	NEEDLE BRUSH	.25
17016	CERAMIC PICK UP CARTRIDGE (45 R.P.M.)	3.00
17067-A	GRIP SWITCH LEVER ASSEMBLY	.65
17133	GRIPPER SPRING	.10
17148	IDLER WHEEL ASSEMBLY	1.75
17149	IDLER TENSION SPRING	.15
17150	SPRING PLATE ASSEMBLY	1.25

MODEL 1438

<u>PART NO.</u>	<u>DESCRIPTION</u>	<u>PRICE</u>
17151	ROTOR SHAFT PULLEY SPRING	.10
17152	CAM TRACK SPRING (R.H.)	.15
17153	CAM TRACK SPRING (L.H.)	.15
17160	TURNTABLE WITH CENTER LOCATOR	3.00
17170	MOTOR CLAMPING PLATE	.30
17181	GRIPPER ARM DECAL (ODD)	.10
17182	GRIPPER ARM DECAL (EVEN)	.10
17220	OUTPUT TRANSFORMER	7.00
17221	POWER TRANSFORMER	10.50
17224	CENTER KEY SWITCH	6.00
17227	COUNTER KNOB	.30
17275	MINIATURE 5 PRONG SOCKET	.25
17276	MINIATURE 4 PRONG PLUG	.45
17304-A	GRIPPER ARM ASSEMBLY	9.00
17310	RUBBER RING	.55
17312-A	RECORD KEEPER ASSEMBLY	.40
17316-A	RECORD MAGAZINE ASSEMBLY	65.00
17318-A	TRAY AND KEEPER ASSEMBLY	.95
17322	REVERSING SWITCH TRIP BRACKET (R.H.)	.15
17323	REVERSING SWITCH TRIP BRACKET (L.H.)	.15
17328-A	SELECTOR BOTTOM PLATE ASSEMBLY	
17334-A	SELECTOR UNIT ASSEMBLY	115.00
17339-A	CARRIAGE CONTACT BLOCK ASSEMBLY	2.00
17354-A	5 WIRE CABLE ASSEMBLY	3.85
17432-A	COIL PLUNGER ASSEMBLY USE #17977-A	.80
17440-A	TRAY RIVETING ASSEMBLY	.75
17445-A	MICRO SWITCH LEVER ASSEMBLY	.55
17451	COUNTER ARM	.15
17452	COUNTER WIRE	.05
17462	TURNTABLE MOTOR (45 R.P.M.)	9.50
17470	GRIPPER SHAFT GEAR	.45
17473	TOPE ARM MOUNTING PLATE	.35
17475	TOPE ARM PAWL	.05
17486	DOPE EXTRUSION (R.H.)	2.50
17487	" " (L.H.)	2.50
17489	DOPE EXTRUSION (FRONT)	3.50
17491	DOPE GLASS	13.60
17492	PLASTIC PILASTER	6.00
17493	DOPE HINGE	1.20
17494	DOOR HINGE (BOTTOM)	.20
17495	DOOR HINGE (TOP)	.65
17498	LIGHT SHIELD	1.80
17499	PROGRAM WINDOW	6.00
17503	DOPE LATCHING BAR	.45
17505	DOPE GLASS SIDE PANEL	2.55
17521	TOPE ARM PIVOT PLATE	.55
17524	TOPE ARM CAM KEEPER SPRING	.05
17533	TOPE ARM SPRING	.10
17539	LIFTER LEVER STUD	.20
17540	PAWL STUD	.10

MODEL 1438

<u>PART NO.</u>	<u>DESCRIPTION</u>	<u>PRICE</u>
17543	PAWL LEVER SPRING	.05
17547	TONE ARM REST PIN	.05
17549	TONE ARM BEARING	.10
17551-A	GRIPPER UNIT ASSEMBLY	42.50
17552-A	GRIPPER HOUSING (WITH BEARING AND STUD ONLY)	10.25
17555-A	TRUNNION SHAFT ASSEMBLY	6.50
17557-A	GRIPPER DRIVE SHAFT ASSEMBLY	7.50
17564-A	RACK - COUNTER ASSEMBLY	3.60
17565-A	COUNTER AND RAIL ASSEMBLY	21.50
17569-A	COUNTER SHAFT AND CAM ASSEMBLY	1.60
17572-A	ACCUMULATOR COVER ASSEMBLY	1.50
17574-A	ACCUMULATOR ASSEMBLY COMPLETE	28.50
17584	PROGRAM CHANGE BUTTON	.25
17585	COIN SLOT CASTING	.50
17586	PROGRAM CHANGE CASTING	.55
17587	COIN RETURN CUP COVER	.25
17593	DRESS CAP	6.00
17595	4 PRONG PLUG	.30
17596	4 PRONG SOCKET	.30
17599	INTERLOCKING RELAY (D.C.)	12.50
17604	CONTROL CIRCUIT TRANSFORMER	10.00
17610-A	DOOR ASSEMBLY	265.00
17611	PROGRAM DRIVE MOTOR	12.00
17612	REJECT BRACKET	.60
17613	MAGAZINE AND GRIPPER MOTOR	30.00
17615-A	DOME ASSEMBLY	26.00
17616	RATCHET PLATE	.15
17619	15" SPEAKER	40.00
17621	POWER RECTIFIER	12.00
17649	DOME PLASTIC LIGHT SHIELD	2.00
17651-A	DOOR WELDING ASSEMBLY	45.00
17665	PROGRAM CHANGE SWITCH	.75
17667	TRIM MOULDING	.75
17676	REJECT BUTTON	.35
17677	REJECT BUTTON EXTENSION	.35
17679	MICRO SAFETY CAM - INNER	.65
17681	PROGRAM RELAY	3.25
17682	DOME EXTRUSION (BACK)	2.85
17686	SELECTOR BUTTON (RED)	.10
17689	TURNTABLE MOUNTING STUD	.25
17693	14-15-20 WATT BALLAST	1.25
17696	PROGRAM MAIN SHAFT	3.00
17697	TONE ARM GROMMET	.07
17704	SELECT WINDOW	.25
17705	PROGRAM CHANGE WINDOW	.25
17706	COINS WINDOW	.25
17708	MIRROR GLASS (R.H.)	2.25
17709	" " (L.H.)	2.25
17712	LIGHT SOCKET (L.H.)	.35

MODEL 1438

<u>PART NO.</u>	<u>DESCRIPTION</u>	<u>PRICE</u>
17713	LIGHT SOCKET (R.H.)	.65
17714	LIGHT SOCKET (DOME)	.35
17715	DOME ESCUTCHEON	.70
17716	FRICTION WASHER (LEATHER)	.25 DZ.
17220	STEEL WASHER	.07
17721	PERFORATED GRILLE	4.00
17722	5¢ - 10¢ AND 6 FOR 25¢ DECAL	.10
17723	5-10-25¢ DECAL	.10
17724	10¢-25¢ DECAL	.10
17733	OAK PANEL DECAL	1.80
17734	WALNUT PANEL DECAL	.70
17742	CHASSIS MOUNTING SPRING	.20
17749	LIFTER LEVER SPRING	.10
17751	FRICTION SPRING	.05
17759	FLEXIBLE CHUTE	1.50
17761	REJECT BUTTON CABLE	.05
17764-A	KEYBOARD CUT-OUT SWITCH ASSEMBLY	4.00
17766-A	KEYBOARD CUT-OUT SWITCH CAM ASSEMBLY	1.45
17769-A	SLUG REJECTOR ARM LINK ASSEMBLY	.75
17774-A	TONE ARM BRACKET ASSEMBLY	1.20
17776-A	LEVER AND PAWL ASSEMBLY	.60
17779-A	PIVOT PLATE ASSEMBLY	1.20
17782-A	LOCK LEVER GUIDE PLATE ASSEMBLY	.40
17784-A	LIFTER LEVER AND STUD ASSEMBLY	.35
17786	COUNTER CABLE	.05
17787	CABLE HOUSING	.10
17790	.47 MFD. 200 V. CONDENSER	.50
17790-A	TONE ARM ASSEMBLY	7.50
17791-A	TONE ARM CASTING ASSEMBLY	2.00
17792-A	INPUT PLUG ASSEMBLY	1.40
17796-A	AMPLIFIER ASSEMBLY (LESS TUBES)	45.00
17803	.015 MFD. CAPACITOR	.25
17804	BRUSH WIRE	.20
17807-A	REVERSING SWITCH ASSEMBLY	5.60
17817-A	VOLUME CONTROL ASSEMBLY	3.75
17825	PLUNGER RETURN SPRING	.40 DZ.
17830-A	MOUNTING BRACKET AND STUD ASSEMBLY	1.90
17832-A	SPRING LEVER AND STUD ASSEMBLY	.50
17833-A	COUNTER LINKAGE ASSEMBLY	.35
17837-A	MOTOR MOUNTING BRACKET ASSEMBLY	1.50
17838-A	GRIPPER MOTOR ASSEMBLY	31.50
17839-A	MAGAZINE AND PINION ASSEMBLY	31.00
17840-A	REVERSING SWITCH LEVER ASSEMBLY	.60
17842	CANCEL COIL (D.C.)	.70
17846-A	CARRIAGE ASSEMBLY COMPLETE	11.00
17848	START RELAY (D.C.)	3.75
17849	CANCEL RELAY (D.C.)	4.75
17850-A	POWER DISTRIBUTION PANEL ASSEMBLY	45.00
17870-A	CONTROL BOX ASSEMBLY	34.50

MODEL 1438

<u>PART NO.</u>	<u>DESCRIPTION</u>	<u>PRICE</u>
17881-A	DOM E BRACKET ASSEMBLY	.50
17885-A	PROGRAM HOLDER ASSEMBLY	57.50
17888	PROGRAM HOLDER (FRONT) 1-30	4.75
17889	" " " 31-60	4.75
17890	" " " 61-90	4.75
17891	" " " 91-120	4.75
17895-A	LOCK LATCH ASSEMBLY	.75
17899-A	CASH BOX AND LOCK ASSEMBLY	5.25
17902-A	COIN CHUTE RIVETING ASSEMBLY	1.50
17909-A	DOM E PLASTIC LIGHT SHIELD ASSEMBLY	3.25
17911	DOM E LIGHT BALLAST	1.75
17914-A	REJECT BUTTON & CASTING ASSEMBLY	1.60
17925-A	ANIMATION CYLINDER ASSEMBLY (R.H.)	4.00
17926-A	" " " (L.H.)	4.00
17934-A	PROGRAM TRANSFER SWITCH ASSEMBLY	2.50
17935-A	DRESS PANEL ASSEMBLY (R.H.)	6.50
17936-A	" " " (L.H.)	6.50
17937-A	REAR DOOR ASSEMBLY	18.00
17946-A	CONTACT ASSEMBLY	1.00
17956	RECORD KEEPER SPRING	.25 DZ.
17970-A	PILASTER LIGHT BRACKET ASSEMBLY	6.50
17977-A	COIL PLUNGER ASSEM.	.80

SER. 7 - 12/3/53