



Service Bulletin

AMI INCORPORATED • 1500 UNION AVENUE, S. E. • GRAND RAPIDS 2, MICHIGAN

July 5, 1956

BULLETIN NO. 127

TO: All Distributing Office Service Personnel

SUBJECT: F-3755 Variable Reluctance Cartridge

In recent months numerous F-3755 Cartridges have been returned to the factory. In the majority of cases nothing has been wrong with the cartridge except that the stylus was no longer centered properly between the pole pieces.

It is suggested that before returning any cartridge, it be carefully examined to determine whether or not the stylus is properly adjusted. The centering adjustment is pointed out pictorially on page 25 of the G-200 Operator's Guide and on page 23 of the Model "G" Operator's Guide.

Readjustment of the stylus is easily accomplished by moving the stylus to its desired position with the thumb nail, match stick or similar device.

APPLICATIONS ENGINEERING

/hc